



# Pick-a-Kit

# ***Kitchen Design Guide***

---

Proudly Manufactured by:



A.B.N. 123 802 496 75

A.C.N. 099 040 865

***MONDAY - FRIDAY 8am - 5.30pm***

***SATURDAY 9am - 2pm***

***SUNDAY Closed***

192 Princes Highway,

Dandenong VIC 3175

Phone: (03) 9793 4233

Fax: (03) 9792 5046

EMAIL: [info@plyboard.com.au](mailto:info@plyboard.com.au)

website: [www.plyboard.com.au](http://www.plyboard.com.au)



DIY kit kitchen system!

## Pick-a-kit KITCHEN DESIGN KIT:

Something to think about before you start?  
Consider the following points:

- How many people need to be catered for?
- How much storage space is required?
- Do you intend eating in the kitchen?
- What type of food do you need to prepare?
- What type of appliances will you have?
- How much work area do you need?

The following cabinets are essential in a kitchen design:

### SINK CABINET

Ensure that your sink bowls fit between the walls of your cabinet. Cabinets 555 Deep are standard to suit flush sinks.

### DRAWERS

Try to keep away from corners to avoid handles clashing.

### PANTRY

How often do you shop, if you bulk buy you will need larger than normal storage?

### FRIDGE

Is your fridge big enough? Which hand does it open?  
Do you need a cabinet above?

### COOKTOP / RANGEHOOD

Is your cooktop gas or electric and are you having a rangehood above? Remember the minimum height clearances of your rangehood, electric is approximately 600mm while gas is approximately 650mm. All these sizes will need to be checked for exact regulations with the appliance manufacturer and council specifications.

### OVEN

Are you having an underbench oven under the cooktop, or do you have enough room for a wall oven? If you have an upright stove ensure that you leave a gap of 10mm clearance to the benchtop on each side.

### DISHWASHER

Are having a dishwasher? Allow a minimum of 640 opening space, which includes a filler on each side. The dishwasher should be located as close to the sink as possible.

All sizes of appliances and installation requirements should be ascertained before designing your new kitchen. Check with your local council about the requirements of some kitchen installations.

## What goes where? Some helpful hints:

The position of your appliances will depend mainly on your power and water supply. The sink and dishwasher will need water and waste supply and is usually best situated under windows.

It is best to leave the area above the sink free of any wall cabinets.

Gas hotplates and ovens should be kept near the gas supply the other appliances such as the oven, hotplate, rangehood, microwave and fridge all need a power supply. Thought should be given to where power points are to be located above the bench for small appliances such as electric kettles and toasters.

It will be more economical if all these appliances can be left near their supplies, but do not feel that you are tied to these positions permanently. Gas lines and electrical supplies can be moved to a much user-friendly spot but these can only be moved by licensed tradespersons.

All tall units such as pantries, wall ovens and fridge towers should be kept together. There has to be a space of 300mm between the hot plate /stove and a combustible wall. Stoves and hotplates should not be placed in front of windows where draughts can effect their efficiency and where curtains or blinds can be set alight.

Make sure that the rangehood cabinet is directly above the stove/hotplate for maximum efficiency.

When using a sink with a draining board remember to put the draining board on the side you're most comfortable, depending on what hand you are. If you are having a dishwasher it is has to go under the draining board.

Remember to allow enough space for door openings, such as dishwasher, oven, pantries and kitchen entry doors. Also allow enough space for the amount of people to use the kitchen and walk around safely.

Microwaves should not be any higher than shoulder height of the person that is the primary user of the kitchen.

Finally the kitchen has to be practical as well as being efficient, you will need to think carefully about the layout of your new kitchen, and once it is up and running it should be a pleasure to work in.

# SETTING OUT YOUR NEW **pick-a-kit** KITCHEN.

When assessing the requirements for your new kitchen take the time to write a few notes about what you like and do not like about your current kitchen.

First make a rough plan of what you would like to do on a separate piece of paper.

Study the brochures on any new appliances you propose to use, but do not make any firm decision at this stage because in many cases the available space will dictate what appliances you can use.

## **Measure the Kitchen Area:**

You are now ready to design and measure your kitchen. When measuring your kitchen remember to measure to the nearest **millimetre**, always use a pencil in case of mistakes, and always double check your measurements or get a friend to check them with you.

## **Where to Start?**

Select your starting point and call this wall #1. And then work your way around to the right.

## **WALLS**

Measure each wall starting at # 1, the measurement should be taken at a height of 900mm off the floor level, this will be the bench top height. Now measure the height of the wall, if a bulkhead exists measure from the floor to the underside of the bulkhead and then measure the height of the bulkhead to give an overall room height.

## **DOORS**

It is important to note the width of each door; the measurement should include the architrave on each side of the door. Take the measurement from the corner of the kitchen to the edge of the architrave and do the same from the other side of the architrave to the next corner.

## **WINDOWS**

It is the same for the windows but take the height the window is off the floor and then the overall height of the window.

## **HANDY HINT**

To ensure the above measurements are correct, firstly note the overall width of the wall. Then separately measure the door width and the widths on each side of the door these should tally and match your overall width.

## **PLUMBING**

To locate the plumbing on your layout measure the distance from the left-hand corner to the centre of the outlet pipe under the sink, the same can be done for tap fittings as well as the gas line.

## **ELECTRICAL**

To locate the power points or light switches on your layout measure the distance from the left-hand corner of the wall. The height of the power points and switches from the floor should also be noted.

## **APPLIANCES**

The type of appliances can affect the layout of your kitchen. Please list your choice of appliances, noting which are gas, in the space provided on your layout grid. Remember to list all of your appliances. Eg: refrigerator, stove, wall oven, hotplate, sink, (bowl size), microwave, dishwasher, range hood, and any other speciality appliance that is needed.

## **OTHER**

If there is any other features that will influence the design of your kitchen, such as heater vents make sure that these are noted on the plan.

## **★ Pick-a-kit Cabinets:**

Before positioning any cabinets your plan should feature any or all of the above items.

Door styles and types can also dictate the size of cabinets used. Some timber doors can not be made under 300mm wide. Also there is some restrictions on minimum and maximum heights.

Decorative panels and infills can also have bearing on the overall size of your kitchen. Remember that on the end of some of the cabinets you will need a decorative end panel, the bench top will then usually overhang by about 25mm.

By looking through our **pick-a-kit** cabinet catalogue you'll see, that most of our cabinets are made up from modules starting at 300mm increasing up to 1200mm in width; it merely requires you to select the required cabinets to suit your design.

Of course your room is unlikely to be an exact multiple of 100mm and your walls cannot be relied on to be even or square, so work your cabinets out to the closest 100mm under size so a filler can be used to make up the required space. The gap can also be taken up if you are having a dishwasher or an upright stove.

## **Using the right code.**

We have over 70 cabinets that can help you construct your new kitchen. You will see the codes and sizes on the cabinet production list. If you need more information on any of the cabinets, look through the cabinet description to follow:

In our **pick-a-kit** catalogue you will notice that each cabinet has it's own code. A base cabinet that is 600mm wide is called a **BD 600**, **BD** standing for base deep.




# SAMPLE ROOM MEASUREMENT GUIDE


ALL MEASUREMENTS MUST BE IN MILLIMETERS.

SHOULD YOU HAVE ANY DIFFICULTIES,  
CONTACT OUR SALES STAFF FOR ASSISTANCE.

KEY	
☆	SINK WASTE
●	POWER OUTLET
△	WATER SUPPLY
☀	GAS SUPPLY



Starting point on Grid Sheet.



A base deep is 555mm deep while a base narrow is only 455 deep, base narrow is mainly used on island benches. All base cabinets are a standard 720mm high.

A wall unit or overhead cabinet that is 600mm wide is called a **WT 600**, **WT** standing for wall tall. A wall tall cabinet is 720mm in height and 300mm deep.

We also supply cabinets that are called wall small. A **WS 600** is a cabinet that is only 360mm in height and 300mm deep. These units can be used above rangehood cabinets and also above fridges.

Pantry units that are 600mm wide will be called a **PD 600**. **PD** standing for pantry deep. The height of the pantry carcass is 2125mm. It then sits on our standard kicker, which is 145mm in height and will have an overall height of 2270mm. The depth of our pantries is 575mm.

The broom cabinet that is 600mm wide has a code, which is **BR 600**. **BR** standing for broom, their height and width is the same as the pantries.

The appliance pantry sits on top of the bench top it's code is **APP 600**. **APP** stands for appliance and the 600 would be the width. The appliance pantry has a height of 1370, which, when sitting on the bench, comes to an overall height of 2270mm. The depth of these units is 400mm.

A walk-in pantry has a code of **PCNR 1000**. **PCNR** stands for pantry corner and only comes in in one size of 1000mm deep. The pantry height is 2270.

Our draw units are a standard 720mm high and a standard 555mm deep. They have 3 different widths; 400, 450 and 500mm. Their code is **DDR 450**; the **DDR** stands for deep drawer. The 450 would be the width of the drawer unit. Each unit comes complete with 4 drawers and runners. One cutlery insert is included.

Our pot drawers come as a standard 720mm in height and a standard 555mm in depth; their widths vary in size with the sizes being 600, 700, 800 and 900mm. Each unit comes with 2, 16mm solid pot drawers complete with 500mm drawer runners. The code for the pot drawers is **PDR 600**, **PDR** stands for pot drawer and the 600 is for width of the unit.

The corner units are a standard 720mm high and 880mm along the two back wall sections, the depth of the ends are 555mm. You must remember to put the adjustable shelf in the cabinet before it is fully assembled. The code for these units is **BCD 880**; **BCD** stands for base corner deep.

We also have a variation of this unit. It is also a standard 720 in height but it is only 780 across the back sections. The ends on this unit are only 455mm deep. The code for this unit is **BCN 780**; (**BCN** stands for base corner narrow. The 780 is the measurement along the back.)

When used in conjunction with 555 deep carcasses, this unit will form a cavity or void behind it. It is often necessary to use a **BCN780** where obstructions are found in corners where a full depth cabinet will not fit in.

The wall corner unit has a standard height of 720mm. The measurement across the back is 600mm and it has ends of 300mm. This is the only size the unit comes in. The code for this unit is a **WTC 600** (**WTC** stands for wall tall corner.) And the 600 is the measurement along the back.

All of our wall oven units are made to order depending on the size of the oven.

The wall oven is usually made up of a **WS 600** at the top then there is a cupboard that houses the oven with a **PDR600** (pot drawer) underneath. The height of this pot drawer unit is decided by the height of the oven. The wall oven unit has an overall height of 1970mm a depth of 575mm and an overall width of 600mm. The code for this unit is **TOWER 600**. The 600 is the width of the unit. If you have an extra wide oven the unit can be made 700mm wide; this would now become a **TOWER700**.

If you require a microwave in your wall oven this can be accommodated for.

The **WS600** would be at the top of the tower, underneath you would have the microwave box, which is 450mm high, this box will be in the same colour as the door finish. Directly below is the wall oven cabinet and below that would be a single pot draw (**PDR600-1**). The height of this drawer is decided solely by the size of the oven.


If you are having an under-bench oven it will have to be incorporated in a cabinet. The majority of ovens will fit in a **UBO 600**, which stands for under bench oven and the 600 is the width. The cabinet will need a panel under the oven that matches the doors.

We can supply a range of three different open display units. These are usually made in the same finish as the door colour or finish. The first is a wall corner unit; this unit goes on the end of the overhead cupboards and gives you a space to display ornaments or nics.




# Kitchen Component List

## FLOOR UNITS




Base Cabinet		Door	
Code	Size H x W x D	QTY	Size H x W
BD300	720 x 300 x 555	1	717 x 297
BD400	720 x 400 x 555	1	717 x 397
BD450	720 x 450 x 555	1	717 x 447
BD500	720 x 500 x 555	1	717 x 497
BD600	720 x 600 x 555	2	717 x 297
BD700	720 x 700 x 555	2	717 x 347
BD800	720 x 800 x 555	2	717 x 397
BD900	720 x 900 x 555	2	717 x 447
BD1000	720 x 1000 x 555	2	717 x 497
BD1100	720 x 1100 x 555	2	717 x 547
BD1200	720 x 1200 x 555	2	717 x 597

## WALL UNITS




Wall Cabinet		Door	
Code	Size H x W x D	QTY	Size H x W
WT300	720 x 300 x 300	1	717 x 297
WT400	720 x 400 x 300	1	717 x 397
WT450	720 x 450 x 300	1	717 x 447
WT500	720 x 500 x 300	1	717 x 497
WT600	720 x 600 x 300	2	717 x 297
WT700	720 x 700 x 300	2	717 x 347
WT800	720 x 800 x 300	2	717 x 397
WT900	720 x 900 x 300	2	717 x 447
WT1000	720 x 1000 x 300	2	717 x 497
WT1100	720 x 1100 x 300	2	717 x 547
WT1200	720 x 1200 x 300	2	717 x 597

## BROOM UNITS




Broom Cabinet		Door	
Code	Size H x W x D	QTY	Size H x W
BR600	2125 x 600 x 575	2	2122 x 297
BR700	2125 x 700 x 575	2	2122 x 347
BR800	2125 x 800 x 575	2	2122 x 397
BR900	2125 x 900 x 575	2	2122 x 447
BR1000	2125 x 1000 x 575	2	2122 x 497

## PANTRY UNITS




Pantry Cabinet		Door	
Code	Size H x W x D	QTY	Size H x W
PD600	2125 x 600 x 575	2	2122 x 297
PD700	2125 x 700 x 575	2	2122 x 347
PD800	2125 x 800 x 575	2	2122 x 397
PD900	2125 x 900 x 575	2	2122 x 447
PD1000	2125 x 1000 x 575	2	2122 x 497

## APPLIANCE PANTRY UNITS




Appliance Pantry Cabinet		Door	
Code	Size H x W x D	QTY	Size H x W
APP450	1370 x 450 x 400	1	1367 x 447
APP600	1370 x 600 x 400	2	1367 x 297
APP700	1370 x 700 x 400	4	1367 x 172
APP800	1370 x 800 x 400	4	1367 x 197
APP900	1370 x 900 x 400	4	1367 x 222

## RANGEHOOD & FRIDGE UNITS




Rangehood & Fridge Cabinet		Door	
Code	Size H x W x D	QTY	Size H x W
WS600	360 x 600 x 300	2	357 x 297
WS700	360 x 700 x 300	2	357 x 347
WS800	360 x 800 x 300	2	357 x 397
WS900	360 x 900 x 300	2	357 x 447
WS1000	360 x 1000 x 300	2	357 x 497

## WALK IN CORNER PANTRY UNITS




Walk in Corner Pantry Cabinet		Door	
Code	Size H x W x D	QTY	Size H x W
PCNR1000	2270 x 1000 x 585	1	2255 x 560

## POT DRAWER UNITS




1, 2 and 3 Pot Drawer Cabinet's		Drawer Front	
Code	Size H x W x D	QTY	Size H x W
PDRIN1600	360 x 600 x 555	1	357 x 597
PDRIN1900	360 x 900 x 555	1	357 x 897
PDRIN600	720 x 600 x 555	2	357 x 597
PDRIN700	720 x 700 x 555	2	357 x 697
PDRIN800	720 x 800 x 555	2	357 x 797
PDRIN900	720 x 900 x 555	2	357 x 897
PDRIN3600	720 x 600 x 555	3	237 x 597
PDRIN3700	720 x 700 x 555	3	237 x 697
PDRIN3800	720 x 800 x 555	3	237 x 797
PDRIN3900	720 x 900 x 555	3	237 x 897

## CUTLERY DRAWER UNITS




Cutlery Drawer Cabinet		Drawer Fronts	
Code	Size H x W x D	QTY	Size H x W
DDRIN400	720 x 400 x 555	4	177 x 397
DDRIN450	720 x 450 x 555	4	177 x 447
DDRIN500	720 x 500 x 555	4	177 x 497

## WALL BIFOLD CORNER UNITS



Wall Bifold Corner Cabinet		Door		
Code	Size H x W x D	QTY	Size H x W	16/18/20mm
WTC600	720 x 600 x 300	2	717 x 277	16
WTC600	720 x 600 x 300	2	717 x 276	18
WTC600	720 x 600 x 300	2	717 x 275	20

## FLOOR BIFOLD CORNER UNITS



Floor Bifold Corner Cabinet		Door		
Code	Size H x W x D	QTY	Size H x W	16/18/20mm
BCD880	720 x 880 x 555	2	717 x 304	16
BCD880	720 x 880 x 555	2	717 x 302	18
BCD880	720 x 880 x 555	2	717 x 300	20




# WALLOVEN UNITS

Waloven Units are 2270mm high and can be either 600 or 700mm wide.


The style in which it is made can be up to you to suit your kitchen needs.

Below are three options (A,B,C) you can choose from. When ordering a Waloven unit make sure you specify the style .

Waloven Cabinet		Door	
Code	Size H x W x D	QTY	Size H x W
TOWER600	2270 x 600 x 575	2	<b>ASK</b> x 297
TOWER700	2270 x 700 x 575	2	<b>ASK</b> x 347




## MICROWAVE SHELF UNITS



Microwave Shelf Cabinet	
Code	Size H x W x D
MW600	400 x 600 x 450
MW700	400 x 700 x 450

## DISPLAY UNITS



## OPEN CORNER WALL UNITS

Open Corner Wall Cabinet	
Code	Size H x W x D
WOS300	720 x 300 x 320

## OPEN CORNER FLOOR UNITS

Open Corner Floor Cabinet	
Code	Size H x W x D
BOS300	720 x 300 x 575

The WOS 300\* cabinet stands for wall open shelf. It has a height of 720mm and has a width of 300mm; the depth is 320mm which will allow it to cover the door edge of the cupboard next to it.

The base unit to match is a BOS 300.\* This unit has a height of 865mm which includes a kicker of 145mm the width is 300mm and it has a depth of 575mm. This is deep enough to cover the door of the cupboard next to it.

The last display cabinet is the micro unit. This cabinet's size can be changed to suit the size of the microwave. If you do not specify the size of your oven our standard sizes will be supplied, those sizes are 400mm in height and 450mm deep. The width will be 600mm, the code for this unit is a MW 600\*, the MW standing for microwave. This cabinet can be made 700mm wide if needed.

## **PANELS AND INFILLS.**

On the end of your cabinets you may need a decorative end panel. This will hide the white cabinet and cover the gap made by the kicker. These panels can be made in the same finish as the doors.

The panel on the end of the standard cabinets is 865mm in height and 575mm wide and is edged on one long edge only. The code for this is a BASE END PANEL. If you have a narrow base cabinet the size would be 865mm high and only 475mm wide and it would be edged one long edge. The code would be a NARROW BASE END PANEL.

If you are having an island bench the end panel will have to be wider to accommodate the island back panel. The panel will have it's standard height of 865mm but it's width will now be 595mm, it will now have to be edged on it's two long edges. The code now becomes an ISLAND BASE END PANEL. For narrow cabinets the code is ISLAND NARROW BASE END PANEL.

When having an island bench you will need a panel on the back of the cabinets. The code for this will be a BAR PANEL. The height again is a standard 865mm but the length of the cabinets will determine the width.

Depending on the finish of the panels the island back may have to be joined together, there is no need for edging on any of the ends.

When cabinets are against a wall, it is often necessary to fit an INFILL PANEL. Infill panels come to you sized 720 x 100 edged-one-long for base and wall cabinets.

\* Please Note: Codes followed by an asterisk are non-stock and are made-to-order.

When your total cabinet measurement is less than the overall size of the wall you will need to put in an infill. The height of these infills is 720mm; the width is determined by the size of the gap that you will need to fill, the infill will come over size so you can trim it to an exact size if the wall is out of level. The maximum width of the infill will be 100mm. These infills are screwed on to the side of the cabinet flush with the front edge.

When you have tall cabinets such as pantries or fridge towers you will need a panel on the side that will be seen. The size of this panel will be 2270mm in height and 600mm in width. The panel will be edged on one long edge.

The code for this panel is DEEP PANTRY END PANEL, which stands for pantry panel. If you had a narrow pantry the code would be NARROW PANTRY END PANEL, which stands for pantry narrow panel.

If the pantry butts up to a wall you will need an infill, this could be left on its edge or it could be trimmed to size if your wall is out of level. The size of the infill is 2270mm in height and 100mm in width and would be edged on one long edge. The code for this infill is PANTRY INFILL PANEL.

If you are using a WS600 you will need a panel on both sides of your rangehood cabinet. This will cover any of the exposed white carcass of your overhead cabinets. This same panel can go on the end of the wall tall cabinets. The sizes of these panels are 720mm high and 320mm deep and they are edged on one long edge and two short edges. The code for these panels is WALL END PANEL.

If your overhead cabinets don't reach the adjacent wall you will need an infill to fill the gap, again these are 720mm in height but only 300mm deep, the width of the infill is determined by the gap left, the maximum width is 100mm.

When you have an appliance cupboard you may need to have one of the ends covered with a seen panel or infill. The size of the panel required to cover the end will be 1370mm in height and 420mm wide, it will be edged on one long edge. The code for this panel is APPLIANCE END PANEL.

If you need to fill a space between the appliance cabinet and the wall you will need an infill. The size of an infill is 1370mm in height and comes to a maximum 100mm wide. It will be edged on one long edge and can be sat on edge if screwed into the side of the cabinet flush with the front. The code for infill is APPLIANCE INFILL PANEL.

Kickboards come in a standard size of 2400mm long and 145mm high. They are supplied in a long length so you can cut them to the size required. The code for the kickboards is KICKRAIL.

The bulkhead is a panel that sits above the wall cupboards between the cupboards and the ceiling to fill in that space if desired. The bulkhead width is solely dependant on the ceiling height and the standard size is 2400mm long and 285mm high TO BE CUT ON SITE.. The code for the bulkhead is BULKHEAD.

At the top of the overhead cabinets you can fit a decorative capping mould, which can be supplied in several different finishes. Capping mould is supplied in long lengths, which you can cut to the required size. The code for the capping is CAP MOULD.

Each base cabinet regardless of their depth requires 4 adjustable legs which can be adjusted to keep your cabinets level. The code for the adjustable legs is B.L 4.

The corner cabinets will require 5 adjustable legs. The code for the adjustable legs is B.L 5.

The adjustable legs installation details is included in this manual.

There is a large range of hardware accessories available, which include many types of rubbish bins, wirebaskets, cutlery trays, carousels, and pull out pantry units and towel rails. All of the fittings are optional extras, and they may be fitted in your cabinets at the time of construction or later. Refer to page 7 of the order form for available accessories.

## DOORS:

We can supply a large range of different door types, which include;

### SQUARE EDGE MELAMINE.

There is a vast range of colours in melamine board including white, all doors and drawers are edged all around and come complete with the hinges.

### M.D.F (Medium density fibre-board)

M.D.F is a range of doors that can come in flat panel door or to a standard routed door. The door comes in a raw finish and can be painted and comes complete with hinges and timber handle or knob.

### HARDFORM (Round edge doors)

Hardform doors come in two profiles which are "L" or "U". There are many colours within the range to choose from. Once again the doors come complete with their hinges and a range of four standard handles.

### NATURAL TIMBER VENEER.

Natural timber veneer has a large range of different species of veneer. All doors and drawers will be edged all round and come complete with hinges and timber handle.

### VINYL. (Vacuum formed doors)

There are 21 different designs and 18 different colours to choose from. The hinges and a choice of four standard handles come with each door.

### TIMBER

Species: Tasmanian Oak, Radiata Pine, Tasmanian Blackwood, American White Oak and Jarrah.

Just to name a few, there are various styles in each species. We supply the doors in their raw or polished state.

Please note that true door styles, samples and colours can be seen on display in our kitchen showroom.

## BENCHTOPS:

If you decide to have a laminate top you have the choice of many different colours and textures and edge treatments, (such as front edge post-formed in 180 or 90 degree.)

If using timber doors you can have your benchtop with a matching timber edge with a routed mould on the front edge.

You can give your kitchen a country look by having a solid timber benchtop. There is a large range of different timber species that can be catered for. All solid timber tops come raw. ***The polishing is left up to you.***

If you wish to use a granite or similar product we can supply the raw H.M.R substrate (High Moisture Resistance) to support your granite.

All joins will be machined and supplied ready to be joined on site by the customer.

We **DO NOT** do the cut outs for sinks or hotplates as this can lead to problems with sinks or hotplates not lining up with respective feeds. Pre-cutting cut-outs can also cause a weakness when transporting.

Benchtops will be supplied with the benchtop joiners and biscuits, to join the tops together; flashing behind the sink area can also be supplied and will need to be specified when ordering.

The laminate sample colours and the different solid timber species samples for your benchtop are available for you to choose.

***It is recommend that a Silicone Bead is used when joining bench tops (Not P.V.A.)***

# Benchtops

## 35mm Benchtops.

600 / 900 Deep

### Styles Available:

Postform PF180:

Square-Edge

Timber-Edge

Postform PF90:

Square-Edge

Timber-Edge

### Laminate Available:

Nevamar

Wilsonart

Formica

Laminex

*Standard and Gloss Finishes are available.*



Many sample laminates available  
in our store for you to pick and  
choose from!

### Polished or Unpolished Solid Timber Available:

Species:

American White Oak

Blackwood

Pine

Tasmanian Oak


Jarrah

Myrtle




# Standard Kit Carcase Heights and Depths

Front View




Side View






# Instructions for fitting the HETTICH Korrekt Height Adjustable Legs.


## Leg Block



## Adjustable Leg



## Clips



black



black/self-colour

## Each Leg Assembly Requires:


- 1 061 854 Leg Block ( A )
  - 1 061 853 Adjustable Leg ( B )
  - 1 "C" Clip ( C )
  - 1 Adjustable Plinth Attachment ( D )
- } 061 855
- 4 WBX40 Leg Block Screws 10 x 1-1/2 Pozidrive
  - 2 WBX06 Adjustable Plinth Attachment Screws 4 x 5/8 Pozidrive

## Directions:

1. Locate Leg Block ( A ) as indicated on the diagram. Make sure Leg Block ( A ) is set back 50mm from the front edge and 1mm from the the side of the carcasse.  
Important Note: Set the Leg Block back 70mm on pantry units.
2. Fix Leg Block ( A ) with 4 x 10 x 1-1/2 pozidrive screws.
3. Slide C-Clip ( C ) onto Adjustable Plinth Attachment ( D ).
4. To determine the placement of the C-Clip and Attachment on the kick rail, first lay the kick rail face down on the floor against the adjustable leg and move to position you want it to finish.
5. Mark the location of the centre of the leg (s) which will recieve the C-Clip.
6. Centre the adjustable slide attachment over the mark and fix using 2 - 4 x 5/8 pozidrive screws.
7. Tilt the kickrail towards the leg (s) and press until C-Clips engage.



# YOUR DESIGN COULD LOOK SOMETHING LIKE THIS!



● HINGE HOLES

## CABINET LIST

3 x BCD880	Base Corner Deep	1 x WT300	Wall Tall
1 x BD800	Base Deep	1 x WS600	Wall Small (Rangehood)
1 x BD500	Base Deep	1 x WS800	Wall Small (Rangehood)
1 x DDR450	Deep Drawer	3 x P.D.P	Pantry Deep Panel
1 x UBO600	Under Bench Oven	2 x W.T.P	Wall Tall Panel
1 x BD300	Base Deep	2 x W.T.I.P	Wall Tall Infill Panel
1 x PD600	Pantry Deep	1 x B.I.D.F.P	Base Island Deep Floor Panel
3 x WT800	Wall Tall	1 x B.I.B.P	Base Island Back Panel
1 x WT500	Wall Tall	2 x B.I.P	Infill Panel

Now you should have some understanding of all the elements of designing. You can now start to put your dream kitchen together piece by piece. We hope this manual has been informative, giving you a feeling of confidence that you have been able to design and develop a kitchen a professional would be proud of.

*Please note that the contents of this manual are to be treated as a guide only.* Plyboard Distributors Pty Ltd will not be responsible for any costs that may be incurred from design or installation of your kit kitchen. Council or government requirements will override any recommendations in this manual.

If you have any further queries, please do not hesitate to contact staff at Plyboard Distributors, as we will respond to any questions you may have.

***Phone Kitchen Department.***

PH: 9793 4233


Fax: 9792 5046





**PLYBOARD DISTRIBUTORS**  
192 PRINCES HIGHWAY, DANDENONG VIC 3175  
TELEPHONE: (03) 9793 4233 FAX: (03) 9794 0972  
EMAIL: info@plyboard.com.au

STARTING  
POINT



6000mm ( 6m )

6000mm ( 6m )

DESIGN SHEET FOR: \_\_\_\_\_  
CUSTOMER'S ADDRESS: \_\_\_\_\_  
PHONE NUMBER: \_\_\_\_\_ WORK: \_\_\_\_\_  
FAX: \_\_\_\_\_ DATE: \_\_\_\_\_

One Square = 100 x 100mm